

Name SCRUBBING SHOWER GEL

No. 1012

Description | This deep-cleansing, scrubbing, body gel formulation exfoliates the skin and leaves it clean,

radiant, and velvety to the touch.

Formulation INGREDIENTS: % by Weight Functionality

Deionized Water q.s. to 100.0 Carrier Carbopol ETD2020 (Lubrizol) Acrylates/C10-30 Acrylate 1.0 Thickener

Glycerin (Dow) 1.5 Humectant

STEPAN-MILD® PCL

AMPHOSOL® HCG (or AMPHOSOL® HCG-HP)

Merquat 550 (Calgon) Polyquaternium-7

55.0 Primary Surfactant
9.6 Secondary Surfactant
3.0 Conditioning Agent

Lipo APS 40/60 (Lipo Chemical) Crushed Apricot Seed

Lipo WSF 35/60 (Lipo Chemical) Walnut Shell Powder

Sodium Hydroxide, 50% solution

Citric Acid, 50% colution

Citric Acid, 50% colution

Citric Acid, 50% colution

Citric Acid, 50% solution q.s. Viscosity Modifier Preservative, Dye, and Fragrance q.s. pH Adjuster

Total 100.0

Procedure

Stability

1. Charge vessel with Deionized Water. Start agitation.

2. Slowly sprinkle in Carbopol ETD2020. Mix until completely dispersed.

3. Add Glycerin, STEPAN-MILD® PCL, AMPHOSOL® HCG (or AMPHOSOL® HCG-HP), and Merquat 550. Mix well.

4. Add Lipo APS 40/60 and Lipo WSF 35/60. Mix until homogeneous.

5. Adjust pH to 5.0-6.0 with Sodium Hydroxide, 50% solution or Citric Acid, 50% solution.

6. Add Preservative, Fragrance, and Dye.

*Note: When formulating with AMPHOSHOL® HCG-HP, a greater amount of Citric Acid, 50% solution, may be needed to adjust the pH within the recommended range as noted, than when formulating with AMPHOSOL® HCG.

Physical Appearance at 25°C Translucent, thick liquid

Properties pH, as is 5.0–6.0

Viscosity at 25°C, cps 40,000–50,000

Storage/ 4 weeks at 25°C Stable

4 weeks at 45°C Stable
4 weeks at 5°C Stable

Three freeze/thaw cycles Passed

Instructions Apply to wet skin, lather, and then rinse. for Use

Provides good foaming and cleansing property.

External

Comment

Marketing Notes: BCI = 86. Total Biorenewable Carbon Index (BCI) was calculated only for the Stepan surfactants used in this formulation. For further information on Stepan's BCI, visit

www.stepan.com.

Registered Trademarks of Stepan Company STEPAN-MILD® AMPHOSOL®

For Additional Assistance For applications or product handling assistance, call our Technical Service Department at 1-800-745-7837 (U.S.) or 011-334-76-505-100 (Europe).

For ordering assistance, call our Account Service Department at 1-800-457-7673.

The information contained herein is based on the manufacturer's own study and the works of others and is subject to change without prior notice. The information is not intended to be all-inclusive, including as to the manner and conditions of use, handling, storage or disposal or other factors that may involve additional legal, environmental, safety or performance considerations. Nothing contained herein grants or extends a license, express or implied, in connection with any patents issued or pending of the manufacturer or others, or shall be construed as a recommendation to infringe any patents or to violate any applicable laws. STEPAN COMPANY MAKES NO WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR USE, AND NO WARRANTY OR GUARANTY OF ANY OTHER KIND, EXPRESS OR IMPLIED, IS MADE, INCLUDING REGARDING PERFORMANCE, SAFETY, SUITABILITY, STABILITY, ACCURACY, COMPLETENESS, ADEQUACY OR OTHERWISE. Stepan Company (and its employees, subsidiaries and affiliates) shall not be liable (regardless of fault) to the vendee, its employees, or any other party in respect of this information, including in respect of its accuracy, completeness, adequacy, furnishing, use, or reliance upon, and the vendee assumes and releases Stepan Company (and its employees, subsidiaries and affiliates) from all liability, whether in tort, contract or otherwise.



Stepan Company Northfield, Illinois 60093 Telephone (847) 446-7500

Revision Date: 12/19/2016 Publication Date: 04/26/2007 © 2016, Stepan Company. All rights reserved.