

Name PEARLESCENT CONDITIONING SHAMPOO AND BODY WASH

No. 1013

Description This pearlescent shampoo provides good foam and conditioning properties that can also be

utilized as a body wash.

INGREDIENTS: Formulation % by Weight Functionality

> q.s. to 100.0 Carrier Deionized Water 0.3 Conditioning Agent

UCARE Polymer JR-400 (Amerchol) Polyquaternium-10

Glycerin

STEPAN-MILD® PCL

AMPHOSOL® HCG (or AMPHOSOL® HCG-HP)

Glycol Stearate Panthenol (Roche) Sodium Chloride Citric Acid, 50% Solution Sodium Hydroxide, 50% Solution Preservative. Dve and Fragrance

0.5 Pearlescent Agent 0.2 Additive g.s. Viscosity Builder q.s. pH Adjuster q.s. pH Adjuster

36.7 Primary Surfactant

9.6 Secondary Surfactant

0.5 Humectant

a.s. Additive

Total 100.0

Procedure

- 1. Charge vessel with Deionized Water. Start agitation.
- 2. Slowly sprinkle in UCARE JR-400. Mix until completely dispersed.
- 3. Add Glycerin. Mix thoroughly.
- 4. Add STEPAN-MILD® PCL and AMPHOSOL® HCG (or AMPHOSOL® HCG-HP), mixing until homogeneous.
- 5. Heat to 68°C-71°C (155°F-160°F). Add Glycol Stearate. Mix for 25 minutes.
- 6. Start cooling. At ambient temperature, adjust pH with Sodium Hydroxide or Citric Acid. Adjust viscosity with Sodium Chloride, if necessary.
- 7. Add Panthenol, Mix.
- 8. Add Preservative, Dye, and Fragrance as desired.

*Note: When formulating with AMPHOSHOL® HCG-HP, a greater amount of Citric Acid, 50% solution, may be needed to adjust the pH within the recommended range as noted, than when formulating with AMPHOSOL® HCG.

Physical **Properties** Appearance at 25°C Pearlescent liquid

pH, as is 6.5 - 7.03,500-5,000 Viscosity at 25°C, cps

Storage/ Stability

1 month at 25°C Stable 4 weeks at 45°C Stable

Instructions for Use

Apply shampoo to wet hair, lather, and then rinse.

External Comment

Marketing Notes: BCI = 85. Total Biorenewable Carbon Index (BCI) was calculated only for the Stepan surfactants used in this formulation. For further information on Stepan's BCI, visit

www.stepan.com.

Registered Trademarks of Stepan Company STEPAN-MILD® AMPHOSOL®

For Additional Assistance For applications or product handling assistance, call our Technical Service Department at 1-800-745-7837 (U.S.) or 011-334-76-505-100 (Europe).

For ordering assistance, call our Account Service Department at 1-800-457-7673.

The information contained herein is based on the manufacturer's own study and the works of others and is subject to change without prior notice. The information is not intended to be all-inclusive, including as to the manner and conditions of use, handling, storage or disposal or other factors that may involve additional legal, environmental, safety or performance considerations. Nothing contained herein grants or extends a license, express or implied, in connection with any patents issued or pending of the manufacturer or others, or shall be construed as a recommendation to infringe any patents or to violate any applicable laws. STEPAN COMPANY MAKES NO WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR USE, AND NO WARRANTY OR GUARANTY OF ANY OTHER KIND, EXPRESS OR IMPLIED, IS MADE, INCLUDING REGARDING PERFORMANCE, SAFETY, SUITABILITY, STABILITY, ACCURACY, COMPLETENESS, ADEQUACY OR OTHERWISE. Stepan Company (and its employees, subsidiaries and affiliates) shall not be liable (regardless of fault) to the vendee, its employees, or any other party in respect of this information, including in respect of its accuracy, completeness, adequacy, furnishing, use, or reliance upon, and the vendee assumes and releases Stepan Company (and its employees, subsidiaries and affiliates) from all liability, whether in tort, contract or otherwise.



Stepan Company Northfield, Illinois 60093 Telephone (847) 446-7500

Revision Date: 12/19/2016 Publication Date: 03/07/2008 © 2016, Stepan Company. All rights reserved.